


FlexBlend Surface-Mounted, Suspended

SM340C SP340P



## Emergency Lighting Installation instructions




































5 Charge time



6 Test minimum 5 seconds







Emergency Light type	Driver		Duration	Number of battery cells	Nominal voltage	Rated lumen output	Symbol
	type	power					
	TrustSight BASIC	3-5W	3 h	I NIMH 4,8V 4.0Ah 19.2Wh	220240V 50/60Hz	-	ELB3
	TrustSight PRO	3-5W	3 h	I NIMH 4,8V 4.0Ah 19.2Wh	220240V 50/60Hz		ELP3
	TrustSight DALI	3-5W	3 h	I NIMH 4,8V 4.0Ah 19.2Wh	220240V 50/60Hz		ELD3
	ILB EM LED Driver	3W	3 h	NiMH 7.2V 2500mAh	1638V 50/60Hz		ELE3
	ILB EM LED Driver	6W	1 h	NiMH 7.2V 2500mAh	1638V 50/60Hz	PCS=500lm/1hrs MLO/O=400lm/1hrs	ELE1

## LED indicators status

LED indicator (colour / flashing)	Error condition	Cause	Solution		
Green / no		System OK, battery fully charged			
no indication		mains off, EM mode, Rest mode, test in prog	gress		
Green / slow		System OK, battery is charging			
Green / fast		System OK, recently tested (< 5 days, Austra	ystem OK, recently tested (< 5 days, Australia mode only)		
RED / no	Battery voltage too high or too low	No battery connected	Connect a battery		
		Wrong or bad battery connected	Replace battery		
RED / fast	Output voltage too low or too high	Wrong LED load connected	Connect a right load and perform		
			functional test		
	no load connected or output shorted	Wrong connection	Connect a right load and perform		
			functional test		
RED / slow	Failed test due to battery	Battery end of life	Replace battery and perform a duration test.		
		Charger failure	replace driver		
		DALI identify device			

RED -Green/ fast

Fast flashing: f = 2 Hz (on-time = 250 ms, off-time = 250 ms) Slow flashing: f = 0.66 Hz (on-time = 250 ms, off-time = 1250 ms)

## Maintenance instructions

To assure the lighting quality of this unique LED lighting concept there are a few instructions regarding the maintenance of this LED luminaire:

- Do not touch electronic components! Electronic components are under high voltage. Electronic components are ESD sensitive.
- $\blacksquare$  During installation or when maintaining the luminaire please use static free gloves to avoid marks on the luminaire.
- To remove dirt and spots use the following:
  O Dust: only use micro fiber cloths

  - Fingerprints, etc.: use a cleaner for synthetic materials with antistatic properties.
- Do not stare into the LED light beam.
- To avoid scratches and dirt on optical parts remove protective foil after installation.
- The luminaire shall be installed by a qualified electrician and wired in accordance with the latest IEE electrical regulations or the national requirements.
- $\blacksquare$  The ligh source in not replaceable. In case of damage replace the luminaire.
- Driver insulation: Basic according to IEC 61847-1







**ATTENTION OBSERVE PRECAUTIONS** FOR HANDLING **ELECTROSTATIC SENSITIVE DEVICES**