

# INSTALLATION INSTRUCTIONS

## CLEARSCAPE COLOR FILTER

### TOOLS REQUIRED:

- FLATHEAD SCREWDRIVER
- PHILIPS HEAD SCREWDRIVER

1. REMOVE 4X SET SCREWS FROM CORNERS OF HOUSING

2. INSTALL 4X THREADED SPACERS

3. ALIGN CLEARANCE HOLES OF COLOR FILTER WITH SPACERS.

4. ATTACH USING 10-24 SCREWS AND #10 WASHERS

