

INSTALLATION INSTRUCTIONS

SLENDERFORM POST TOP MOUNTED ON 3" X 4" TENON

IMPORTANT : READ ALL INSTRUCTIONS BEFORE PERFORMING ANY WORK. BE SURE ALL POWER IS OFF PRIOR TO INSTALLING LUMINAIRES.

WARNING: FIXTURE MUST BE GROUNDED IN ACCORDANCE WITH APPROPRIATE CODES. FAILURE TO DO SO MAY RESULT IN SERIOUS INJURY.

NOTE: THIS INSTALLATION INSTRUCTION SHEET IS FOR THE AUTOMATIC PROFILE DIMMING POLE MOUNTING INSTRUCTIONS ARE PROVIDED WITH MOUNTING HARDWARE

1. CONNECT LEAD WIRES FROM SLENDERFORM TO INCOMING POWER LEADS BY JOINING LIKE COLORS.
2. FIT UNIT ONTO TENON AND SECURE WITH PROVIDED 6X 1/4-20 SET SCREWS.

