

# Zhaga kit

1. Loosen the 4 screws of the original Cover.
2. Remove the Cover and loosen the screw of the ground wire.
3. Unpack the cover with the Dali connector and the wires (3 colors).
4. Connect the wires to the Tyco connector in the order shown in the picture. Red wire in 1, Gray in 2 and Pink in 3.
5. Screw the earth wire to the Cover with a torque of 1Nm. Use the original screw.
6. Insert the 3 wires in the same color connectors, according to the picture.
7. Place the Cover with the pre-mounted screws.
- Tighten the screws in the order of the Roman numbers (I,II,III,IV), use a torque of 2Nm
8. Remove the cap to install a sensor.

