

THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE APPLICABLE INSTALLATION CODE BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED.

1. BEFORE BEGINNING, TURN OFF POWER AT CIRCUIT BREAKER.
2. REMOVE CAP NUTS K AND LOCKWASHERS J FROM LANTERN.
3. DISCONNECT QUICK DISCONNECT H.
4. USE WALLPLATE C AS A TEMPLATE TO LOCATE THE 4 HOLES FOR ATTACHING THE WALLPLATE TO THE WALL. DRILL (4) 1/2" DIA. HOLES X 1 1/8" DEEP IN WALL.
5. INSERT 4 LAG SHIELDS B INTO WALL.
6. WIRE FIXTURE BY CONNECTING WIRES FROM THE SOURCE TO THE CORRESPONDING WIRES FROM THE LANTERN IN QUICK DISCONNECT A. SPLICE THE THREE LEADS FROM THE LANTERN TO THE INCOMING POWER CABLE - BLACK TO BLACK, WHITE TO WHITE, AND GROUND TO GROUND.
7. ATTACH WALL PLATE C TO WALL WITH SILICONE (SUPPLIED BY CONTRACTOR) AND LAG SCREWS D.
8. SCREW THREADED RODS E INTO WALL PLATE C AND SECURE IN PLACE USING LOCKWASHERS F AND LOCKNUTS G.
9. CONNECT QUICK DISCONNECT H.
10. POSITION BALLAST HOUSING ASSEMBLY I OVER WALL PLATE C AND SECURE IN PLACE USING LOCKWASHERS J AND CAP NUTS K.

SEE NOTE 4

