

by (signify

## Wall Mount

LytePro Wall

LPW7


Small Wall Mount


## LytePro Wall LPW7


## Installation Instructions












Dimension - Overall Fixture



Dimension - Mounting Plate Knockouts


#### Troubleshooting Guide

Symptoms	Possible Cause(s)	Corrective Action
No Light	1. No power to unit. 2. Loose wiring	<ol> <li>Check circuit protection device (circuit breaker, fuse or switch).</li> <li>Recheck wiring connections (with power off)</li> </ol>

**LPW7** Installation Instructions - Cover Plate Accessory

## NOTICE: DO NOT MOUNT LYTEPRO SOLELY TO THIS COVER PLATE. IT IS

NOT INTENDED TO SUPPORT THE WEIGHT OF THE LUMINAIRE.



# (s)ignify

© 2019 Signify Holding. All rights reserved. This document may be subject to change. No representation or warranty as to the accuracy or completeness of the information included herein is given and any liability for any action in reliance thereon is disclaimed. All trademarks are owned by Signify Holding or their respective owners. Signify North America Corporation 200 Franklin Square Drive, Somerset, NJ 08873 Téléphone 855-486-2216 Signify Canada Ltée. 281 Hillmount Road, Markham, ON, Canada L6C 2S3 Téléphone 800-668-9008