

Installation Instructions

PHILIPS


Only for any servicing work
Diffuser frame can be opened (but not recommended)




Open Snap Locks from Diffuser Frame to open the Fitting for access.




Pull Snap Locks from all positions to Open Frame





Product Dimensions




ATTENTION: Install in accordance with national and local building and electrical codes.










PHILIPS









NOTE: DO NOT OPEN ANY SCREWS

