

interact

Wireless gateway
Interact Pro
LCN1840



Installation Instructions


Instructions d'installation
Instrucciones de instalación

Istruzioni per l'installazione
Installatie-instructies

Installationsanweisungen
インストール手順



安裝指示书
إرشادات التركيب

Items delivered
包装内含以下产品








LCN1840

Items not delivered / Tools required
包装内不含以下产品/及工具



1 interact pro app





A portal to access Interact PRO is available at:
<https://sme.interact-lighting.com> (world except China)
<https://sme.interact-lighting.cn> (China)

Note

This product contains open source software. The acknowledgements, license texts and the written offer can be retrieved from the product by opening the http page of this product.

注意

该产品含有开源软件。相关的声明，版权等信息均可通过访问该产品http网页获得

FCC Compliance Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

IC Compliance Statement

This device complies with Industry Canada license-exempt RSSs. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Any changes or modifications not expressly approved by Signify could void the user's authority to operate this equipment. This equipment is intended for commercial use only.

FCC Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance 20 cm between the radiator & your body.

IC Radiation Exposure Statement

(EN) This equipment complies with IC RSS-102 radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance 20 cm between the radiator & your body.

(FR) Cet équipement est conforme aux limites d'exposition aux rayonnements IC établies pour un environnement non contrôlé.

Cet équipement doit être installé et utilisé avec un minimum de 20cm de distance entre la source de rayonnement et votre corps.