

Signify

RF Node

LLC7471, LLC7474



LLC7471



LLC7474




Installation instructions






Instructions d'installation
Instrucciones de instalación

Istruzioni per l'installazione
Installatie-instructies

Installationsanweisungen
インストール手順

安装指示书
إرشادات التركيب





-  Must be installed by a qualified electrician in accordance with all national and local electrical and construction codes and regulations.
- Doit être installé par un électricien qualifié conformément aux codes et réglementations électriques nationaux et locaux du bâtiment.
- La instalación debe realizarla un electricista calificado siguiendo todos los códigos y normativas eléctricas y de construcción, tanto nacionales como locales.
- Devono essere installati da un elettricista qualificato in conformità con le norme locali e nazionali vigenti in materia di costruzioni edilizie e installazione di impianti elettrici.
- Moet door een gekwalificeerd elektricien overeenkomstig alle nationale en lokale elektrische verordeningen worden geïnstalleerd.
- Muss von einem geprüften Elektriker in Übereinstimmung mit allen nationalen und örtlichen elektrischen Codes und Regelungen installiert werden.
- 国または地域の建築コードおよび規制にすべて従い、資格のある電気技師が設置してください。
- 必须根据所有国家和地方的电气和施工准则及规范，由符合资格的电工进行安装。
- حی‌اولاً و نه‌نیز اولاً عی‌م‌چل اق‌فو له‌وم ی‌ی‌اب‌رک ل‌س‌ی‌ک نم بی‌فرست‌ل‌ا ج‌ت‌ی‌ نا بج‌ی‌ء‌اش‌ن‌ال‌ا وء‌اب‌رک‌ل‌ا ب‌قول‌ ع‌ت‌ب‌ل‌ا ق‌یل‌ج‌ل‌ا و ق‌یل‌ط‌ول‌ا

-  Make sure power is OFF
- Assurez-vous que l'alimentation est coupée
- Asegúrese de que la alimentación eléctrica esté desconectada
- Assicurarsi che l'alimentazione sia disattivata
- Zorg dat de voeding is uitgeschakeld
- Vergewissern Sie sich, dass die Stromzufuhr ABGESCHALTET ist
- 電源が OFFであることを確認します
- 确保电源关闭
- قواطل‌ا لی‌غ‌ث‌ت فاق‌ی‌ا نم دک‌ات
-  **Note**
- There shall be an external fuse or MCB in the Line connection with a current rating of 16A or less.
-  **Note**
- RF node can only be used in overvoltage category II environment classified as IT equipment.
- Hereby, Signify declares that the radio equipment type LLC7471, LLC7474 is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following Internet address: www.signify.com/red
-  **Warning**
- Do not use any chemical cleaning agents on the LLC7471 and LLC7474.



© 2021–2025 Signify Holding. All rights reserved. The information provided herein is subject to change, without notice. Signify does not give any representation or warranty as to the accuracy or completeness of the information included herein and shall not be liable for any action in reliance thereon. The information presented in this document is not intended as any commercial offer and does not form part of any quotation or contract, unless otherwise agreed by Signify. All trademarks are owned by Signify Holding or their respective owners.

4422 955 70415, 10 October 2025

UK importer address:
Signify Commercial UK Limited
2 Guildford Business Park
GU2 8XG, UK

www.signify.com/products

