

PHILIPS

LLC7816/00, LLC7817/00,
LLC7818/00






Installation Instructions

Instructions d'installation
Instrucciones de instalación

Istruzioni per l'installazione
Installatie-instructies

Installationsanweisungen
インストール手順

安裝指示書
إرشادات التركيب



LLC781x



LLC7816



LLC7816



LLC7818




4422 964 50623


13 November 2024

www.philips.com/lighting



2b ANSI C136.41




3



4



5



Note

There shall be an external fuse or MCB in the Line connection with a current rating of 16A or less.



Note

LLC7816/00, LLC7817/00 and LLC7818/00 can only be used in overvoltage category II environment classified as IT equipment.



Warning

Do not use any chemical cleaning agents on the LLC781x/00.

