

# Signify

Master Connect Sensor

EasyAir SNM212/w MC

EasyAir SNM212/g MC



SNM212/w MC



SNM212/g MC




## Installation instructions




Instructions d'installation  
Instrucciones de instalación

Istruzioni per l'installazione  
Installatie-instructies

Installationsanweisungen  
instrukcja instalacji

Instruções de instalação  
οδηγίες εγκατάστασης






© 2021-2026 Signify Holding. All rights reserved. The information provided herein is subject to change, without notice. Signify does not give any representation or warranty as to the accuracy or completeness of the information included herein and shall not be liable for any action in reliance thereon. The information presented in this document is not intended as any commercial offer and does not form part of any quotation or contract, unless otherwise agreed by Signify. All trademarks are owned by Signify Holding or their respective owners.

