ADVANCE

MasterConnect Sensor

EasySense SNH212 MC
EasySense SNHB212 MC




SNH212 MC





SNHB212 MC


Installation instructions

Instructions d'installation
Instrucciones de instalación
Istruzioni per l'installazione
Installatie-instructies
Installationsanweisungen
instrukcja instalacji
Instruções de instalação
οδηγίες εγκατάστασης
إرشادات التركيب









IP20

max 55° C
min 0° C


≤85 %

kg
0.016 kg


zigbee


Works with MasterConnect


https://www.signify.com/oem





Height	Minor Movement		Major Movement	
H	X1	Y1	X2	Y2
2.4 m	1.9 m	2.9 m	2.9 m	4.3 m
3 m	2.4 m	3.6 m	3.6 m	5.4 m












Datasheet
Design-in guide



Directive 2014/53/EU

https://www.signify.com/advance/en-us/products/lighting-controls/sensors-and-accessories/signify-masterconnect-luminaire-integrated-sensors-and-accessories/LP_CF_170171205_EU/family?size=8

ADVANCE

© 2026 Signify Holding. All rights reserved. The information provided herein is subject to change, without notice. Signify does not give any representation or warranty as to the accuracy or completeness of the information included herein and shall not be liable for any action in reliance thereon. The information pre-sented in this document is not intended as any commercial offer and does not form part of any quotation or contract, unless otherwise agreed by Signify.

All trademarks are owned by Signify Holding or their respective owners.

21
PAP